



Scoreboard Instructions

To Reset Everything:

1. Press RESET, HOME or VISITOR
 - a. Make sure AUTO HORN is ON before starting game

To Set Time:

1. Press in the time, then press CLOCK SET

Entering a Penalty:

1. Press “:00”, then enter length of penalty
2. Press HOME PEN or VISITOR PEN

To Add Goals:

1. Press HOME or VISITORS

Stop/Start the Clock:

1. Use the TOGGLE SWITCH