



North Rink Scoreboard Instructions

Set & Run Game:

1. Press NEW GAME, CLEAR
2. Press "1", this will direct the timer to count down
3. Select period # and press ENTER
4. Select length of period (minutes) and press ENTER, ENTER
5. Press TIME RUN (to start clock) and TIMER HOLD (to stop clock)

Penalty Set-up:

1. Press HOME or GUEST PENALTY, press ENTER
2. Enter player's #, press ENTER
3. Type in # of minutes, press ENTER, ENTER

To Remove Penalties:

1. Press RECALL PENALTY, CLEAR, ENTER

Set & Reset Score:

To increase score:

1. Press HOME or GUEST SCORE

To reset score:

1. Press RECALL, HOME/GUEST SCORE, CLEAR, Enter Score, ENTER

Starting New Period:

1. Press PERIOD, select desired period #, ENTER
2. Follow steps 4& 5 under "Set & Run Game" Instructions

Reset Timer (Game Time):

1. Press SET TIMER
2. Type in desired minutes, press ENTER

Aborting Time Out:

1. Press TIME OUT, CLEAR, ENTER